




## USING THE TENNIS BALL MACHINE

The tennis ball machine is battery operated – it will last between 2 and 3 hours on a full charge. When you are done using the machine, please ensure that it is plugged in and charging before you lock up the storage shed. The light on the charger will turn red (indicating that the machine is charging); the light turns green when the machine is fully charged.

Do not store tennis balls in the machine – use the ball hoppers provided. Always ensure the machine is powered off before adjusting its position or filling the ball hopper. Do not allow the machine to run without balls in the hopper to launch.

Position the machine along the centerline of the court. Place it at the baseline for faster shots, and nearer the service line for slower shots. Turn the machine 'ON' and set the controls to produce the desired ball throws. Refill the hopper. Turn the machine 'OFF' and wait for five seconds to allow the 10 second start-up time delay to reset. Turn the machine 'ON' (and Oscillator 'ON' if desired) and walk to your playing position. Use the Remote control to manage the ball feed and oscillation setting. Once the hopper is empty, please turn off the machine before gathering balls to refill the hopper.





The blue device is the remote control.

Enable the remote by pressing the circled switch.

The top button toggles the ball feed between on and off.

If the oscillator button is in the "On" position, then the bottom button will toggle the oscillator between on and off.

This is the Ball Trajectory Adjustment.

Loosen the ball trajectory knob by turning it a few turns counter-clockwise. Brace the machine with one hand and move the ball trajectory knob with your other hand. Move the knob up (towards 5) to increase the arc of the ball launch. Move the knob down (towards 1) to decrease the arc of the ball launch. When the ball launch is at the desired trajectory, tighten the knob firmly against the case by turning clockwise.

